KUKA





KUKA.PLC mxAutomation

Integrated Robot-Based Automation







Status quo without mxAutomation

Current solution of robot-based handling in/at production cells or machines (machine tools, injection molding, die-cast machines, etc.)

- Cell is controlled by a (Soft) PLC
- Robot is controlled by a robot controller
- → Experts of PLC and robot programming are needed
- one is depending to the other during commissioning and programming
- → Longer set-up time
- Operator knows to manage the cell via machine/cell controller for Robot actions support from an expert is necessary
- → High maintenance and life cycle costs

Vision:

- Production cells or machines where all components including the robot are programmed and commanded by its existing machine controller environment
- → easy to program and easy to use for the end-users







mxAutomation – all included in customers cell/machine concept


The concept:

- mxAutomation allows programming and commanding a KUKA Robot from a connected PLC
- The programmer/operator can set up, program and diagnosing the robot from the cell- or machine control (PLC), means in the environment he is familiar with
- Nearly all features and functions of KSS are available
- KRC and its mechatronic and safety functions are controlling all movements
- Robot programming skills are not required
- The operator has the same HMI in different applications

How it works:

- Part of mxA is an extensive library, mostly function blocks (FB's), which will made available on the Engineering suite of the PLC
- FB's will linked in the PLC language for sequence programming
- In execution mode the parameters are transmitted to the KRC via fieldbus cyclically
- On KRC site they are interpreted, executed, and the results are reported back to the PLC cyclically





KUKA.PLC mxAutomation| PM Christina Heckl | Mar 2023 | www.kuka.com





mxAutomation – value propositions

Use KUKA.PLC mxAutomation for commanding KUKA Robots in your language

High integration for user friendly automation solution

- Convincing concept KUKA Robot is a participant of the PLC controlled cell or CNC machine tool
 - Consistent HMI for different applications
 - Everything can be done by one programmer/operator
 - No specific robot knowledge necessary for commissioning, programming and operating
- · Much shorter configuration and set-up time
 - programming and diagnosis over PLC- or machine HMI
 - Simple robot commanding via function blocks
 - Nearly all KSS features can be used (e.g. Conveyor synchronization, vector move etc.)
 - KUKA.LoadDataDetermination callable from mxA
- Many KUKA technology packages are usable
- Lower cost per part short cycle times and high product quality at minimized production area
 - Fast motion profile and high accuracy path planning of robot controller
 - KUKA.SafeOperation or KUKA.SafeVelocityMonitoring (options)

mxAutomation








mxAutomation – supports a wide range of PLCs

- Siemens
 - SINUMERIK (Run myRobot)
 - STEP 7 V5.4, S7-300 and S7-400
 - STEP 7 (TIA Portal), S7-300 and S7-400
 - STEP 7 (TIA Portal), S7-1500
 - TIA-Portal (SIMATIC)
 - SIMOTION
- 3S / CoDeSys
- AllenBradley / Rockwell
- NI / LabView

- Robots in Architecture (RIA)
- Beckhoff / TwinCat
- Schneider-Electric / Modicon
- B&R / X...
- Lenze / PLC
- Mitsubishi / CNC controller
- C++ oder C#

- Supported by the most popular RT Ethernet protocols
 - Profinet / ProfiSafe
 - EtherCAT / FSoE
 - EthernetIP / CIPsafety
 - UDP








mxAutomation – KR C4/5 integrated in PLC/machine environment

Project – Configuration – Programming – Diagnose

- Motion programs of the robots are fully integrated in the cell/machine control system and can be archived there
- All operation of the robot can be integrated into the HMI user interface of the system
- Diagnostic messages from the robot are sent to the cell/machine controller for further processed there or displaying on the HMI
- Remote access for service and maintenance (depending on cell/machine controller) extendable to the robot via standard functions











mxAutomation – applications - machine tools

Siemens Sinumerik - Run MyRobot handling

- SINUMERIK commands the robot
- Examples from Siemens are available with complete documentation
- Worldwide support from Siemens and KUKA
- Robot control with a Siemens-Panel

https://www.youtube.com/watch?v=cU3E1R2vRaA&index=1&list=UU6HrPPoLdjNynZCvUrJbmBw

Siemens SIMATIC

- TIA Portal for project configuration, programming & diagnose
- Worldwide support from Siemens and KUKA
- Robot control with a Siemens-Panel
- https://support.industry.siemens.com/cs/document/109482123/controlling-a-kuka-industrial-robot-using-a-simatic-s7-1500?dti=0&lc=en-WW





KUKA.PLC mxAutomation | PM Christina Heckl | Mar 2023 | www.kuka.com





mxAutomation – applications - machine tools

BOSCH Nexeed Integrated Robotics

- Fast commissioning due to standardized robot configuration
- Greatly reduced need for specific KUKA know-how
- Easily adaptable HMI for robot teach-in
- Programming in IEC-61131 programming system
- PLC-side coordinate transformation for vision-guided robot application
- A lot of additional functions: Point list management, pallet handling, space checks, ...
- Simple and fast creation of stable robot applications through provided application template

Nexeed Automation | Bosch Connected Industry (bosch-connected-industry.com)





Nexeed
Integrated Robotics

Nexeed Control plus







mxAutomation – applications - plastic industry

ENGEL

- Single point of operation
 - using either the 22" machine panel or the smart mobile robot panel
- Consistent operation for
 - KUKA industrial robots & ENGEL linear viper robots (up to 3 axes)
- Integrated production datasets
 - Parameters for process and products
 - robot sequences (spline), positions, ...
- Graphical sequence programming

Features

- EUROMAP67 interface
- Vector move
- Flexible safety control for the entire cell / switchable areas for personal safety

ENGEL duo 800 – YouTube









mxAutomation – applications - beverage industry

MEMCO

- Layer formation and palletizing by robots
- 4 x KR40pa's with servo gripper for bushing bottle pack in the right position
- 2 x KR700pa roll grab for palletizing & 1 x KR120pa for intermediate layers
- Drink packages transport, Empty and loaded pallets management

https://www.youtube.com/watch?v=MfQWluIJM2M

BEYER Maschinenbau

- partial renewal of the filling line, capacity 18,000 bottles/hour
- Quantec KR240pa / KR C4 controller
- Combined de-palettizing/palettizing
- Palette handling empties transport, separating, cleaning, inspection, *filling

https://www.youtube.com/watch?v=Kte5NfwJ0j8&t=108s







*separate control system





mxAutomation – applications - food industry

Proxima Centauri

- Cleaning, quality check & cutting of pork casings
- 2 x KR Agilus in the world's first complete solution for automated loading, caliber measurement, detection of perforations/holes, cutting and sorting of natural casings
- Optimized cutting accounting for changing diameters, length and holes by an artificial intelligent-powered algorithm
- Intuitive, user-friendly software interface
 - that can be operated by anyone after just a couple of hours of training
 - For rapid modification of operating parameters
- →A complete, innovative, efficient and delayable solution for sorting and measurements
- SelectiCa Sorter P1 Proxima Centauri Aps (proxima-centauri.dk)





KUKA.PLC mxAutomation| PM Christina Heckl | Mar 2023 | www.kuka.com





mxAutomation – applications - pharma industry

LT Automation, Denmark

- KR3 and KR10 AGILUS are sorting up to 3.000 blood samples a day
- Supports hospital staff and ensures blood sample quality
- Takeing in the transportation box which consist off outer and inner box
- Correct placing is checked by a 3D camara
- Take out the blood samples and sort them for further analysis
- Flexible solution which can be customized

This amazing KUKA robot handles incredible 3,000 blood samples a day! – YouTube



KUKA.PLC mxAutomation | PM Christina Heckl | Mar 2023 | www.kuka.com






mxAutomation – main functions

Motion

- Jogging and teaching via custom handheld
- LinearMove, DirectMove (PTP), CircularMove
 - Approximation
 - Triggers: Switch points on trajectories
 - Sequential control Interrupts, Override, aborts,...
 - Control multiple robots on one PLC (up to 5 Robots)
 - Changing the BASE- and TOOL coordinate systems
- Conveyor synchronisation
- Vector move allows to push the robot by an external force in cartesian directions

Control

- Reading and write digital and analog robot signals
- Reading and quitting (error) messages









mxAutomation – Improvements

mxA V3.3 for KSS8.6/7 (current architecture)

- Implementation of K customer requirements like ENGEL, 3M etc. in coordination with the stakeholders
 - JogMode → much higher usability (delay between pressing the jog button till move robot is much shorter)
 - Forward / inverse transformation inclusive Tool & Base (one command for calculation and Feedback) → faster result/shorter cycle time
 - Abort Commands command active signal, brake reaction configurable → advanced applications
 - Tech functions up to 12 direct return values on call → advanced applications
 - Approaching positions without S&T fewer transformer calculations required → less KRC computing power
 - KRC Initialize detection of an absolute positioning accuracy robot
 - Conveyor tech Features expanded DLIN usable → shorter cycle times
 - Delete Workpiece Delete part on conveyor (component out of reach)
 - LoadDataDetermination (option) callable from mxAutomation
 - Safe velocity monitoring (option) for safe commissioning and jog mode also for SCARA and small robots (new derivate of safe operation technology)




















mxAutomation – outlook

Next version – mxAutomation v4.0

- Further developments in feature improvements and performance
- Implementation of **SRCI** core functions
 - SRCI: Standard Robot Command Interface
 - → Project realization independent of robot brand and plc brand
- New product introduction in Oct 2024

For further information please get in contact with us








mxAutomation – summary

Summary

- mxAutomation enables external controllers to program and command KUKA Robots on the level of KRL instructions
- Robot programming knowhow is not necessary
- All operation of the robot can be integrated into the HMI user interface of the system
- Final execution, motion profile planning, mechatronic and safety control remains on the KR C4/5
- → mxAutomation allows programming and commanding KUKA Robots in your language



KUKA.PLC mxAutomation | PM Christina Heckl | Mar 2023 | www.kuka.com





mxAutomation – Contact Persons

Steffen GüntherKey Technology Manager

Machine Tools

+49 151 14 503 307 Steffen.guenther@kuka.com



Michael Zärle

Support Engineer at Area Support Center (HQ)

CustomerService@kuka.com



Christina Heckl

Product Manager
Application Interfaces

+49 821 797 1776 Christina.Heckl@kuka.com

